



Start & Drive

SECURE COVER

OPTIMISE THE MAINTENANCE AND REPAIR OF YOUR VEHICLE

SERVICES
BY RENAULT TRUCKS



**RENAULT
TRUCKS**

Renault Trucks Secure cover provides increased protection for your vehicle.

An ideal option for operators who control their own maintenance, our 'Secure' cover provides you with an annual safety inspection at any Renault Trucks workshop which ensure that your vehicle meets our excellent safety standards.

This coverage also entitles you to roadside assistance for any warrantable failures and provides you with an extended period of protection after your warranty has come to an end.

Taking your vehicle for inspection allows our qualified Renault Trucks technicians to spot potential problems before they occur - meaning they are often much less expensive to rectify.

Key benefits

ROADSIDE ASSISTANCE in the event of a warrantable failure

ANNUAL SAFETY INSPECTION at a Renault Trucks workshop

EXTENDED PROTECTION for your vehicle after initial warranty ends



**Find out more about our Secure cover:
Talk to your local dealer or visit [renault-trucks.co.uk](https://www.renault-trucks.co.uk)**

Start & Drive - Secure cover

	SECURE STANDARD	SECURE MAXI	
DRIVELINE	Engine gaskets	■	■
	Cylinder block, crankcase, connecting rods and bearings, crankshaft, pistons, flywheel, damper, cylinder head, distribution, valves, camshaft, manifold, breather, turbo charger	■	■
	Water pump, Thermostat	■	■
	Water / oil heat exchanger, Engine fan control	■	■
	Engine oil pump, oil filter housing and gauge	■	■
	Injection pump, Feed pump, Fuel filter housing	■	■
	Electronic control unit	■	■
	Injectors and pipes	■	■
	Air compressor	■	■
	Gearbox: gearbox housing, synchronizers, pinions, shafts, relays, oil pump, sensors	■	■
	Transfer box	■	■
	Rear axle: Hubs reduction, Differential, Shafts	■	■
	Transmissions	■	■
	Electrical / hydraulic retarder – Exhaust brake	■	■
	CHASSIS AND CAB	Battery box	
Spare wheel carrier			■
Complete chassis, Lift axle system			■
Cab structure			■
Doors, door handles, locks (except barrel), hinges			■
Windows motor, Engine trim and defrosting of mirrors			■
Fan and intakes			■
Heating: Demisting, Standalone heating			■
Air conditioning, Climate control			■
Dashboard, Consoles, Coat hanger, Storage			■
Seat belts			■
Fridge			■
Seats and bunk mechanism			■
Mounting, suspensions and tilt of cab			■
Master switch			■
Wiring harness and fixings			■
All ECU's and switches, Sensors, Immobilizer			■
Relays, Horn			■
Signaling lights			■
Wash / wipe mechanism and control			■
Radio and speakers			■
Dashboard instruments, Tachograph			■
Controls, Stalk switch			■
Warning lights			■
Fuel circuit: Pipes, Fuel and AdBlue tanks, Gauges			■
Water coolant circuit: Radiators, Exchangers, Hoses, Expansion tank			■
Air circuit, Fan, Air dryer, Intercooler			■
Oil circuit			■
Vacuum pump			■
Alternator, Starter motor, Voltage regulator			■
Clutch fork, Clutch servo			■
Clutch, gearbox, suspensions control			■
Steering wheel, housing and connecting rods			■
Engine stop control		■	
Suspensions: Shock absorbers, Cushions, Bars		■	
Engine and gearbox suspension mounts*		■	
Power steering, Hydraulic pump*		■	

Secure packages

On both the Secure Standard cover and the Secure Maxi cover the following are checked on an annual basis:

ELECTRICAL CHECK

- Dashboard instruments, warning lights and indicator lamps operation
- Fault codes, multifunction information display
- Fixing condition and connection of batteries
- Lighting condition

BRAKE CHECK

- Braking system
- Brake pads wear, brake lever
- Parking brake operation

DRIVELINE CHECK

- Axles for leakage
- Belts and tensioners condition
- Engine for leakage
- Engine noise and smoke emission
- Gearbox for leakage
- Intake circuit for leakage
- Radiator cores cleanliness
- Transmission play
- Clutch wear

SUSPENSIONS / WHEELS CHECK

- Shock absorbers mounting and condition
- Tyre wear and pressure
- Pneumatic suspension and remote control operation
- Air suspensions

AXLE / STEERING / CHASSIS CHECK

- General condition of wiring fixings support
- Springs, pads and stabiliser bars condition
- Steering mechanism and front hub bearing
- Chassis frame and cross-members conditions

CAB CHECK

- Air conditioning and heating operation
- Front bumper, license plates, radiator grill and lights condition
- General condition of cab
- Locks and remote control operation
- Rear underrun bar and bumpers
- Step wells, side skirts, and mudflaps condition

- Seat belts, horn, screen wipers and washers operation
- Windscreen and rear-view mirrors condition
- Wiper blades condition
- Cab mounting, rotation and unlocking system operation

OTHER CHECKS

- Water presence in compressed air tanks by bleeding
- Fuel and AdBlue tanks for leakage
- General condition and mounting of exhaust line system
- Hydraulic retarder for leakage
- Power take off for leakage
- Presence and mounting of noise shields
- Hydraulic circuit and gear shift for leakage
- Hoses, ducts and pipes condition
- Level of screen wash, clutch fluid, coolant, engine and steering, battery electrolyte
- Chassis, fifth wheel or towing hook greasing

General terms and conditions apply.

Renault Trucks UK, a division of Volvo Group UK Ltd.
Registered Office: Wedgnoek Lane, Warwick, CV34 5YA
Company Number 2190944 - Registered in England

renault-trucks.co.uk

SERVICES
BY RENAULT TRUCKS



RENAULT
TRUCKS